


# EXPLODED VIEW



# EXPLODED VIEW PARTS LIST

No.	Part No.	Description
120	EAB42609901	Speaker,Full Range G1640501 FERRITE 10W 8OHM 82DB 100HZ 150X40 TRACK LUG EMSONIC
△ 200	EAJ41970710	PDP,Module-XGA PDP42G120001.ADLGB XGA 42INCH 1024X768 16/9 PDP DIVISION
201	EBR39594901	PCB Assembly,CTRL ASS'Y 42 G1
202	EBR39712601	PCB Assembly,YDRV ASS'Y 42 X5
203	EBR39595001	PCB Assembly,XRLB ASSY 42 G1
204	EBR39595101	PCB Assembly,XRRB ASSY 42 G1
205	EBR39706801	PCB Assembly,YSUS ASS'Y 42 G1
206	EBR41668901	PCB Assembly,ZSUS ASS'Y 42 X5
240	AJJ35680107	Supporter Assembly,42PG1/2/3, Vertical Supp. Top Assy(Right), SKD
250	AJJ35680108	Supporter Assembly,42PG1/2/3, Vertical Supp. Top Assy(Left), SKD
260	AJJ35680203	Supporter Assembly,42PG3/6, Vertical Supp. Bottom Assy(Right), SKD
270	AJJ35680204	Supporter Assembly,42PG3/6, Vertical Supp. Bottom Assy(Left), SKD
△ 300	ABJ35121804	Cabinet Assembly,42PG20R-MA H5 42 CABINET ASSEMBLY C/SKD
301	ABA36825001	Bracket Assembly,WOOFER PDP - 42 50 60 WOOFER SPEAKER BRACKET ASSY
302	AJJ35122402	Supporter Assembly,42PG2 Supp. Filter Top Assy WITH PACKING
303	AJJ35122502	Supporter Assembly,42PG2 Supp. Filter Bottom Assy With Packing
304	AJJ35122602	Supporter Assembly,42PG2 Supp. Filter Right Side Assy With Packing
305	MDJ42350902	Filter,CUTTING ACRYL GLASS FILTER PDP 42 SSC NORMAL (SPUTTER)
306	AJJ35122702	Supporter Assembly,42PG2 Supp. Filter Left Side Assy with packing
△ 400	ACQ35123206	Cover Assembly,Rear 42PG1/2 ATSC M-STAR CSKD 42 BACK COVER ASSEMBLY
501	MJH40272402	Supporter,PRESS EGI 1.6 GUIDE EGI 42PG6 Supp_module_guide, SKD, With Pemnut
520	EBR43929101	PCB Assembly,Main PU84A 42PG20-UA - Manual Insert PCB Assembly
560	EBR43329001	PCB Assembly,Sub PU84A 42/50PG20 N. AMERICA MSTAR LOCAL KEY -
561	MBG41119901	Button,Control MOLD HIPS 7 keys hips . 42_50PG2 CONTROL BUTTON 7KEYS
570	EBR43329401	PCB Assembly,Sub SUB M.I PU84A 42/50PG20 N. AMERICA PREAMP -
571	ABA36967701	Bracket Assembly,POWER 42PG6 NON 42PG2/3/6/7 POWER BUTTON ASSY
△ 580	EAY43533901	SMPS,AC/DC PSPU-711A 100VTO120V 400W 50 TO 60 Hz UL/CSA/CE/TUV 42INCH XP2 110 ONLY
590	EBT44191501	Chassis Assembly,SUB PU84A 42PG20 AC-Inlet, Stand Support Ass'y FOR SKD
601	ABA35619217	Bracket Assembly,BRACKET 50PG20-UA PD83A MSTAR(HDMI 3, USB SERVICE ONLY, WITHOUT CI
602	MGJ41163807	Plate.PRESS SBHG 0.8 AV SBHG-A PLATE SUPPORTER MAIN CHASSIS CENTER(MIDDLE) 141.5,
603	MGJ41164512	Plate.PRESS SBHG 0.8 AV SBHG-A VNA42 SUPPORTER MAIN CHASSIS COMMON(SIDE A/V) 141.5
△ 900	AAN35132204	Base Assembly,STAND 42PG1 AF04HA FIXED STAND BASE ASSY SKD
A2	MKJ42519603	Remote Controller,MOLD ABS HF380 PA81A 50PG20-UA ATSC M-STAR